

## SETUP INSTRUCTIONS

- Place the Skydome swag on a flat surface free from sharp debris. The base of the swag is fully waterproof however a tarpaulin or enviro-mat may be placed beneath it.



- Unclip the webbing straps and roll out the swag. Locate the accessory bag and remove the aluminium bows, rods and pegs from their bag



- Sort the aluminium bows into their position. The head and hip bows are the same (larger) size, the foot bow is the smaller size. The body rod is longer than the leg rod.



- Insert the bows one at a time through the canvas sleeve at the apex of the canvas. Insert the ends of the bows into the small eyelet of the reinforced floor tabs. Take care as the bows will be under tension.



- Insert the leg and body rods into the eyelets provided in the apex sleeves. **Note:** The single Skydome has multiple positions for the body rod depending on desired amount of night sky vision.



- Clip the canvas to the head, body and foot bows. The Skydome swag is now free-standing.



- Open doors and storm flaps as required to give access and ventilation to the swag. For security or in adverse weather conditions it is advisable to deploy guy ropes and peg the base to the ground to secure your swag.



## ACCESSORIES

BootSwag



## ARB PRODUCTS - WARRANTY AGAINST DEFECTS

ARB warrants the ARB Products against defects in workmanship and materials for the Warranty Period. If defective workmanship or materials become apparent in the Warranty Period, ARB will replace or repair the defective Product.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the customer under a law in relation to the goods or services to which the warranty relates.

- 1) In this warranty:
  - **ARB** means ARB Corporation Limited (ABN 31 006 708 756) of 42-44 Garden St, Kilsyth Victoria 3137
  - **ARB Outlet** means an outlet which has been authorised by ARB to sell and fit ARB Products
  - **ARB Product** means products which ARB manufactures or for which ARB is the exclusive supplier
  - **Product Information** means the information about the relevant ARB Product which may be contained in any of: documentation provided with the ARB Product, owner's manual, operating manual, service manual or the manufacturer's manual or labels attached to the ARB Product
  - **Warranty Period** means, in respect of an ARB Product, means the period that this warranty against defects applies and which is set out in the table in paragraph 8.
- 2) To be entitled to claim the warranty, the customer must:
  - a) have the ARB Product fitted in accordance with the Product Information
  - b) carry out normal care and maintenance of the ARB Product, including any required by the Product Information
  - c) provide proof of purchase of the ARB Product
  - d) make the claim in the Warranty Period.
- 3) The warranty will not apply in circumstances where the defect is caused by:
  - a) unusual, improper or negligent use or misuse of the ARB Product
  - b) incorrect fitting of the ARB Product other than at an ARB Outlet
  - c) loading the ARB Product with weights in excess of Product Information
  - d) use of non-genuine ARB components in or with the ARB Product
  - e) use on vehicles with modifications not approved in the Product Information or at an ARB Outlet at the time of fitting
  - f) caused by racing or competition use
  - g) use of the ARB Product outside of the requirements of the Product Information.
- 4) The procedure for the customer to claim the warranty is:
  - a) return the ARB Product to the nearest ARB Outlet or contact ARB to arrange a time to bring a vehicle fitted with the ARB Product to an ARB Outlet for inspection. Contact details are in paragraph 7 below if further information is required regarding local outlet details
  - b) bring proof of purchase of the ARB Product to the ARB Outlet
  - c) ARB will review the ARB Product and advise whether the conditions of this warranty have been met
- 5) Where ARB accepts a customer's warranty claim, ARB will rectify any defective workmanship or materials at its own expense.
- 6) Expenses incurred by the customer in claiming the warranty are to be borne by the customer.
- 7) This warranty is given by:

ARB Corporation Limited  
42-44 Garden Street Kilsyth VIC 3137, Australia  
Phone: 03 9761 6622  
Fax: 03 9721 9090  
www.arb.com.au
- 8) The period within which a defect in the ARB Products must appear if the customer is to be entitled to claim the warranty is 2 years or 40,000km (whichever comes first) starting on the date of purchase unless:
  - a) the ARB Product is used in Commercial use. Commercial use means use in industry or commerce including (without limitation) use in the mining industry or as a hire vehicle. In this case, the Warranty Period is the lesser of 1 year or 20,000km, or one third of the period or distance specified in the table, starting on the date of purchase.
- 9) The warranty against defects contained in this document replaces any other warranty against defects or voluntary warranty given in relation to the Products.

Our goods come with guarantees that cannot be excluded under the Australian Customer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



## CARE AND MAINTENANCE

### PRECONDITIONING:

- Your ARB swag is manufactured to Australian Standards and incorporates specially treated canvas with a waxed thread. To waterproof your swag, set it up and thoroughly soak the exterior canvas with water and allow to dry. Repeat this process twice to ensure the seams are waterproof.

### CARE:

- Clean the canvas and PVC base with cold water and a soft bristle brush or sponge only. DO NOT use soaps or detergent as this may damage the coatings on the
- Prevent mildew by packing up the swag 'DRY', wipe dry the PVC base as you roll the swag. Opening the storm flaps to increase ventilation will reduce condensation and assist with drying.
- Erect your swag with increased ventilation to reduce condensation forming on the inner surface of the canvas.
- Your ARB Skydome swag is 'free standing', however in windy conditions ARB recommends it be pegged and guy roped securely.
- DO NOT spray the materials with insect/pesticide aerosol sprays or non-compatible water repellents.
- DO NOT expose any part of the swag to petrol, oil, solvents or similar.
- Your swag is 'free standing' however in windy conditions ARB recommends it be pegged and guy roped securely. Remove pegs with a peg puller or another peg - DO NOT use the peg tab to assist with peg removal.
- Store the swag in a dry place out of direct sunlight.

### LOCATION & USE

- Select a suitable clear and flat site for your swag
- Keep clear of hazards such as falling branches, rising water beds, water ponding and open flames.
- DO NOT use or store combustion appliances inside your swag. e.g. Cookers & Lanterns
- Reduce condensation by improved ventilation, however in some situations condensation should be expected.
- Orientate your swag according to weather conditions. For example:

Keep the side opening to the 'leeward' side of the wind direction.  
Close the internal storm flaps to prevent dust ingress.  
Close the external door flaps to prevent water ingress.  
Keep the mesh closed to keep out insects.  
Open the external and internal flaps for improved ventilation in warm conditions and reduced condensation.  
Position the head flap 'windward' for improved air circulation.

### SUPPLIED PARTS:

- 1 x Swag with mattress and guy ropes
- 1 x Accessory bag consisting of:
  - 8 steel pegs
  - 2 long aluminium bows
  - 1 short aluminium bow
  - 1 long body rod
  - 1 short leg rod